

SPATIALLY-RESOLVED PHOTOLUMINESCENCE MAPPING OF SINGLE CdS NANOSHEETS

Melodie Fickenscher, Lyubov V. Titova, Thang B. Hoang, Amir Maharjan,
Ashu Mishra, Andrei Kogan, Leigh M. Smith, Howard E. Jackson

University of Cincinnati, Cincinnati, Ohio

J. M. Yarrison-Rice

Miami University, Oxford, Ohio

Heesuk Rho, Kyoung-Yeon Lee

Chonbuk National University, Jeonju, Korea

Young-Jin Choi, Lyoung-Jin Choi, Jae-Gwan Park


Korea Institute of Science and Technology, Seoul, Korea

Motivation

- **Semiconductor nanowires and nanosheets exhibit new material properties that are of interest to both basic and applied scientists**
- **We are interested in exploring using single CdS nanosheets to make a sensitive biosensor for biomolecules and pathogens.**

CdS Nanosheet Samples


- Grown by pulsed laser deposition using vapor-phase transport method (800°C; 20min)
- Individual nanosheets were ~50 nm thick; ~4 μm wide and 30-100 μm long
- Surfaces were curved & smooth with uniform thickness.




SEM images of ensemble and single nanosheets

CdS Nanosheet Samples




- HRTEM images show variation in the orientation of the c-axis
- Wurtzite structures exhibit maximum PL emission perpendicular to C axis.
- Want non-destructive way to measure the orientation of the C axis in these samples.



Experimental Setup




Experimental Setup




Low Temperature PL

- PL spectra from several nanosheets show *A- and B- like exciton states*
- Strong PL intensity indicating *high quantum efficiency*





PL Polarization




➤ PL emissions of A- and B-like excitons are *strongly polarized perpendicular to the c-axis*

➤ Consistent with HRTEM




Low Temp PL Imaging



PL spectrum exhibits high variability both along and across the sheet.


Low Temp PL Imaging

- *A- and B-like exciton emissions are spatially separated:* lower energy excitons stronger at the edges while higher energy excitons dominate at the center
- may suggest a spatial distribution of stress in the nanosheet



Time-Resolved PL Imaging



- PL emission at energies 2.547 eV and 2.563 eV (I₂A and I₂B) are the most intense.
- Exhibit time-decays with lifetimes of ~200 ps: shorter than in bulk CdS (~1 ns) but longer than in CdS nanowires (< 50ps)



(*Appl. Phys. Lett.*, 89 053119 (2006))

Photocurrent


- CdS Nanosheets bridging a gap in Titanium contact pads
- Initial measurements show a photo-induced current response to a voltage bias.



Biosensor Development

➤ We will use the CdS nanosheets to make device where the photocurrent responds to the presence of a pathogen.

➤ The next step will be to functionalize the nanosheet with antibodies sensitized to particular biomolecules or bacteria.



Conclusions

- **Strongly polarized PL emission perpendicular to the c-axis -> agrees with HRTEM**
- **High quantum efficiency -> potential applications for nanosheet-based biosensor**
- **Spatial dependence of emission energies -> possible strain distribution in the nanosheets**
- **Exciton decay-time ~200 ps: shorter than in bulk CdS, but much longer than in nanowires**